



Zampa Pets Playpen Folding Instructions



1. Place your playpen on a flat surface, making sure that the panel with the exterior zipper pocket is facing you.



2. Using the top zipper, completely unzip the mesh top and set it aside.




3. Find the playpen panel that has a black elastic band attached, labeled as Panel 1 in the image.



4. Fold Panel 1 to the right, while making sure to keep the elastic band on the outside so it is available for Step 8.



5. Find Panel 5, as labeled in the image. Fold the right corner of Panel 5 inward at Corner A, towards Corner B.



6. Find Panel 3. Fold the right corner of Panel 3 inward at Corner C, towards Corner D.



7. The playpen should now be in an "M" shape and ready to fold.



8. Fold the playpen completely flat. Wrap the black elastic band around the playpen to secure.



9. Put the playpen, mesh top, and any additional parts into the carrying case.

Need Help? If you have any additional questions or concerns, please visit our Contact Us page at zampapets.com.